LifeFitness

ARCTIC SILVER 95Ce Upright Bike



Customer Support Services
PARTS MANUAL rev 18 Aug 2008

Miscellaneous 3
Console Assembly 4
Console Screws and Accessory Tray 6
Alternator w/Pulley 7
Crankshaft and Bearing Assembly 8
Intermediate Shaft and Bearing Assembly 9
Seat Latch Assembly 10
Seat Post Assembly 11
Seat Post Shrouds 12
Idler Bracket Assembly 13
Console Support Assembly 14
Left Side Shroud and Crankarm 15
Right Side Shroud and Crankarm 16
PCB Mounting Bracket Assembly 17
Front Wheels 18
Resistor Assembly 19
Handlebar Assembly 20
Belts 21
Cables 22

Version –04 of model 95Ce has both telemetry and Lifepulse sensors for reading heart rate.

Description	Part No.
POWER SUPPLY: 12V; 4.5A Without Line Cord	118E-00001-0161
LINE CORD: DOM. 10A 125V	0017-00003-0704
LINE CORD: CON 10A 250V	0017-00003-0691
LINE CORD: 10A; U.K.	0017-00003-0889
LINE CORD: AUSTRALIA	0017-00003-0918
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	 0017-00008-0204 0017-00008-0205 0017-00008-0206
HARDWARE KIT	GK63-00002-0056



CONSOLE ASSEMBLY	
Part Number	**Description**
GK63-00002-0063	KIT: SERVICE CONSOLE W/FM NTSC ENG
GK63-00002-0064	KIT: SERVICE CONSOLE W/FM NTSC SPN
GK63-00002-0065	KIT: SERVICE CONSOLE W/FM NTSC JAP
GK63-00002-0066	KIT: SERVICE CONSOLE W/FM NTSC FRN
GK63-00002-0067	KIT: SERVICE CONSOLE W/FM NTSC POR
GK63-00002-0068	KIT: SERVICE CONSOLE W/FM PAL ENG
GK63-00002-0069	KIT: SERVICE CONSOLE W/FM PAL GER
GK63-00002-0070	KIT: SERVICE CONSOLE W/FM PAL SPN
GK63-00002-0071	KIT: SERVICE CONSOLE W/FM PAL FRN
GK63-00002-0072	KIT: SERVICE CONSOLE W/FM PAL ITL
GK63-00002-0073	KIT: SERVICE CONSOLE W/FM PAL DUT
GK63-00002-0074	KIT: SERVICE CONSOLE W/FM PAL POR

OVERLAY BEZEL ASSEMBLY	
Part Number	**Description**
AK63-00247-0001	BZL/SW W/OVERLAY ASSY: MFG; ENG
AK63-00247-0003	BZL/SW W/OVERLAY ASSY: MFG; GER
AK63-00247-0004	BZL/SW W/OVERLAY ASSY: MFG; SPN
AK63-00247-0006	BZL/SW W/OVERLAY ASSY: MFG; JAP
AK63-00247-0007	BZL/SW W/OVERLAY ASSY: MFG; FRN
AK63-00247-0008	BZL/SW W/OVERLAY ASSY: MFG; ITL
AK63-00247-0009	BZL/SW W/OVERLAY ASSY: MFG; DUT
AK63-00247-0010	BZL/SW W/OVERLAY ASSY: MFG; POR


HEADPHONE-JACK ASSY
AK32-00035-0000
TOUCHSCREENS; LCD
0K32-01001-0013
Screw
0017-00101-1811
TAPE: ADHESIVE
0K39-01044-0000
POLAR PCB W/HEADER
AK39-00064-0000
Bracket
0K32-01006-0000
Screws (4)
0017-00101-1843
Inverter Board
GK32-00002-0004
Screws(2)
0017-00101-1813
Interface Boards
A084-92247-A007 NTSC
A084-92247-A008 PAL
Nuts(4)
0017-00103-0084
Single Board Computer
A084-92251-A012
Grommets (4)
0017-00042-1160
Screws (3)
0017-00101-1814
Screws (8)
0017-00101-1852
Console Back Cover
0K32-01003-0000
Screws (7)
0017-00101-1242


Upper Cover
0K63-01145-0001
Lower Cover
0K63-01146-0001
Cover Screws(4)
0017-00101-1744
Console
Mounting Screws(4)
0017-00101-1744
Accessory Tray
0K63-01030-0001
Accessory Tray Screws(4)
0017-00101-1744
Bolts
0017-00101-1755


Alternator Pulley
0K61-02500-0001
Alternator
0017-00009-0841
Brushes
0017-00009-0895
Bolt
0017-00101-0956
Locking Nut
0017-00103-0117
Washer
0017-00104-0044


Crank Arm Hub
Pulley Assembly
AK63-00051-0000
Pulley
0K63-01018-0000
Washers (3)
0017-00104-0458
Flywheel Screws (3)
0017-00101-1715
*Crankshaft & Bearing Kit
GK63-00002-0077
*Crankshaft
*Small Thrust Washer (2)
0K63-01129-0000
*Large Thrust Washer (2)
0K63-01129-0001
*Bowed Retainer Ring (2)
0017-00100-0243
Washer (2)
0017-00104-0409
*Needle Bearing (2)
0K63-01344-0000
*Small Snap Ring (2)
0017-00100-0241
Crank Arm Hub (2)
0K63-01095-0001
Bolt (2)
0017-00101-1705


Clutch Assembly
AK63-00026-0000
(not included in kit)
Magnet
118E-00001-0124
(not included in kit)
Delrin Washers (2)
0017-00104-0455
Retaining Ring
0017-00100-0242
Spacer (not available separately)
Intermediate Bearings (2, not available separately)
Intermediate Pulley
(not available separately)
Intermediate Shaft and Bearing Assembly Kit
GK63-00002-0007


Latch Spring
0K63-01117-0000
Latch Bracket
0K63-01064-0000
NYLINER
0017-00042-1129
E-Ring
0017-00100-0050
Set Screws (2)
0017-00101-0333
Link Shaft Assy.
AK63-00113-0001
Latch Rack
0K63-01061-0000
NYLINER
0017-00042-1129


Deluxe Seat Assy.
AK63-00229-0003
Screw
0017-00101-1750
Lock Washer(4)
0017-00104-0064
Hex Bolt(4)
0017-00101-1121
Seat Post Decal
0K63-01310-0000
Extrusion
Guide Cap
0K63-01044-0000
Seat Adjustment Rack
0K63-01049-0001
Seat Post Assembly
AK63-00099-0001
Spring Support Bracket
0K63-01210-0000
Guide Base
0K63-01045-0000
Pan Screws(3)
0017-00101-1614
Polylastomer Bumper
0017-00042-1131


Left Seat Post Shroud
0K63-01092-0010
Screw
0017-00101-1741
Right Seat Post Shroud
0K63-01092-0009


Idler Bracket
0K63-01050-0000
Lock Nut
0017-00103-0218
Idler w/Bearing
AK63-00008-0000


Console Support
Weldment Assy
AK63-00155-0001
See block diagram
For Cable Part Numbers
Support Screws(4)
0017-00101-1755
End Cap
0K63-01325-0000
Handlebar
Cover, RT
0K63-01192-0003
I-Beam Joint
0K63-01178-0002
Handlebar
Cover, LT
0K63-01192-0004


Shroud Screws(3)
0017-00101-1741
Left Side Shroud
AK63-00179-0002
Crank Arm Screws(3)
0017-00101-1855
Crank Arm, LT
0K39-01042-0008
Shroud Plug
0K63-01084-0001
Decal
0K63-01318-0000
Left Pedal
AK63-00263-0004
Left Pedal Strap
0K63-01238-0004


Right Pedal
AK63-00263-0003
Right Pedal Strap
0K63-01238-0003
Right Side Shroud
AK63-00179-0001
Decal
0K63-01318-0000
Crank Arm Screws(3)
0017-00101-1855
Crank Arm, RT
0K39-01042-0007
Right Side
Shroud Screws(8)
0017-00101-1741


BRKT: PCB-MTG
0K63-01211-0001
PCB-ASSY: POWER-SUPPLY; LCD
B084-92280-A000
GROMMET: PLASTI
0017-00042-0821
Screw
0017-00101-0823


Pan Screw(2)
0017-00101-1747
Wheel Screw
0017-00101-1747
Wheel Insert
0K63-01039-0000
Flat Washer
0K63-01041-0000
Wheel/Bearing Assembly
AK63-00016-0001


Resistor
.5 OHM 240 Watt
100E-00002-0092
Nut(3)
0017-00103-0081
Resistor Mounting Rod
0K63-01166-0000
Retainer
0K63-01215-0000
Pan Screw (2)
0017-00101-1282
Power Control
Cable Assembly
AK63-00029-0001
Resistor Bracket(2)
0K63-01165-0000


Molder Grip
Handlebar
AK63-00156-0001
Electrode
Molded Insert(4)
AK63-00014-0003
Electrode Cable
Assembly
AK63-00028-0001
Insulated Plug(4)
0K63-01167-0001
Handlebar
End Cap(2)
0K63-01114-0001
Phillips Screw(4)
0017-00101-1752



Alternator Belt
0K63-01065-0000



Intermediate Belt
0K63-01066-0001


Head phone Jack SR KIT
SK32-00035-0000
Head phone Jack Cable
AK32-00009-0000
Flat Flex Cable
118E-00001-0178
Inverter Cable
AK32-00032-0000
DC Power Cable
AK32-00075-0002
Coax Cable
AK32-00020-0000
Reed switch and Cable
AK32-00027-0000
Console Power Cable
AK32-00006-0004
Console
Cable
AK32-00026-0004
HR Cable
AK63-00028-0001
HR Extensions Cable
AK32-00022-0000
Polar Cable
AK32-00017-0000
POLAR receiver
AK39-00064-0000